












ASSEMBLY INSTRUCTIONS




PARTS LIST


(ASSEMBLY PARTS)

#1  Table Body 1 set	#2  Left Leg 2 pieces	#3  Right Leg 2 pieces	#4  Wood Holder 1 piece
#5  Pebble 1 piece	#6  Wax 1 piece	#7  Wooden Brush 1 piece	#8  Eraser 1 piece
#9  Pen 1 piece	#10  Handle 1 piece	#11  Stones Colour #1 8 pieces	#12  Stones Colour #2 8 pieces
#13  Leg Leveler 4 pieces	#14  Allen Tool 1 piece	#15  M8X35MM Bolt 16 pieces	#16  19MM Washer 20 pieces
#17  4x32mm Screw 4 pieces	#18  Plastic Anchor 4 pieces	#19  4x32mm Bolt 1 piece	#20  Score Board 1 set
#21  Soft Cover 1 piece	#22  Score 1 piece	#23  Box 1 piece	#24  Puck Colour #2 4 pieces
#25  Puck Colour #1 4 pieces	#26  Adapter 1 piece	#27  3-pc Top Board 1 set	#28  Wooden connector 4 pieces
#29  Leg Panle 2 pieces	#30  M8X75MM Bolt 4 pieces	#31  Remote 1 piece	

STEP 1



STEP 2



STEP 3

